

### User Manual

Code: TOL-32 SATELLITE OPTICAL LNB TOL-32

### Warning!

Please read the user manual included in this work as it contains important information related with safety of installation and use of the device.

Only persons who read the user manual may use the device.

The user manual must be kept because it may be required in the future. The device is to be used exclusively for purposes specified in this user manual.

The device must be unpacked prior to starting-up. After removing the packaging make sure the device is in working order. If the product has defects, it should not be used until it is repaired.

The product is intended for use at home and commercial use and may not be used for other than intended use.

The manufacturer is not liable for damages resulting from not adhering to the rules contained in the user manual, therefore, we recommend to follow the aforementioned safety rules for operation and maintenance of the device. In this way you will ensure yourself safety and avoid causing damage to the device.

The manufacturer and the supplier are not liable for losses or damages arising out of the product, including financial or intangible losses, loss of profits, income, data, pleasure from use of the product or other products related with it - indirect, incidental or consequential loss or damage. The above provisions apply whether the loss or damage concerns:

- 1. Deterioration of quality or the lack of operation of the products or products related with it due to damage as well as the lack of access to the product when it is undergoing repair, which results in stoppage the loss of user's time or a break in business activity;
- 2. Improper results of operation of the product or products related with it;
- 3. It applies to losses and damages according to any legal category, including negligence and other losses, termination of a contract, expressed or implied guarantee and strict liability (even if the manufacturer or the supplier was notified about the possibility of occurrence of such damages).

#### Safety measures:

Particular attention at designing was directed to quality standards of the device where ensuring safety of operation is the most important factor.

The device must be secured against contact with caustic, staining and viscous fluids.

The TOL-32 Optical Satellite LNB is a high performance universal LNB, working in 1310 nm window, provides a wideband optical output where all four polarities are stacked into one frequency range 950-5450 MHz.

Using modern laser technology satellite frequency range can be transmitted via a single fiber over a very large distance, and next can sustain splitting into max. 32 groups. This allows a system setup that can drive a Passive Optical Network (PON) before the signal is finally fed into a number of virtual converters for traditional coax distribution.

The device is powering via coaxial cable.



Input frequency:	10.7 GHz 12.75 GHz
Polarization:	Vertical / Horizontal
Optical output power:	6.5 dBm
Optical power budget:	max. 19 dB (PON)
Optical signal splitting:	max. x32 (PON)





# User Manual

Code: TOL-32 SATELLITE OPTICAL LNB TOL-32

LNB type:	Universal LNB, full-band
Optical connector type:	FC/PC
Power supply:	12 V DC / 450 mA (power adapter included) The device is powering via coaxial cable
Weight:	0.44 kg
Dimensions:	175 x 69 x 110 mm
Guarantee:	2 years

#### Side view:



### Bottom view:




- 1) Power supply
- 2) Grounding 3) FC/PC optical output

Schematic diagram of optical transmission:



## User Manual

Code: TOL-32 SATELLITE OPTICAL LNB TOL-32



- Fiber optic
  Coaxial cable
- 3) Multiswitch
- 4) Attenuator
- In the kit:



**PACKAGE** 

Dimensions (L x W x H): 0x0x0 mm

Gross Weight: 0 kg