

Code: RUD-6-LKY

## HARDWARE KEY **RUD-6-LKY** ROGER

The hardware key RUD-6-LKY is required when using the licensed versions of the VISO EX and RCP Master3 / RCP Master4 programs. The device should be connected to the USB port of the computer on which the license server is installed and separately purchased the appropriate software license.

**ATTENTION!** Regardless of the number of workstations with the VISO EX and/or RCPM3 software, the license server is installed on one computer in the LAN and one key RUD-6-LKY is connected to it.

**Attention!** It is not possible to buy the RUD-6-LKY key alone. It is sold only with RCP / Viso licenses.



Power supply:	5 V DC - from USB port
Operation temp:	5 ... 45 °C
Weight:	0.02 kg
Dimensions:	88 x 30.5 x 14.5 mm
Manufacturer / Brand:	ROGER
Guarantee:	<b>3 years</b>

