

Code: USB/RS485

## CONVERTER **USB/RS485**

The USB/RS485 converter allows to the PC computer the devices controlled via RS-485 interface.

ATTENTION! On hardwares with many COM ports, it may be necessary to check the assigned COM port number. You can do it by: Device Manager -> Ports (COM and LPT). You can change the assigned COM port number using Device Manager - Advanced Options for a port.



Input:	USB
Number of inputs:	1 pcs
Output:	RS-485
Number of outputs:	1 pcs
Communication:	<ul style="list-style-type: none"> <li>• fluent bidirectional transmission (half duplex)</li> <li>• one-directional continuous transmission</li> </ul>
Connectors:	USB Cable terminals
Transmission range:	1200 m (9600 b/s)
Baud rates:	max. 115 kbps
System requirements:	Windows XP/Vista/7/8/10, Linux
Power connector:	USB
Power supply:	from USB port
Guarantee:	2 years