

### User Manual

ALARM CONTROL PANEL INTEGRA-128-PLUS/IT SATEL

## Warning!

Please read the user manual included in this work as it contains important information related with safety of installation and use of

Only persons who read the user manual may use the device.

The user manual must be kept because it may be required in the future. The device is to be used exclusively for purposes specified in this user manual.

The device must be unpacked prior to starting-up. After removing the packaging make sure the device is in working order. If the product has defects, it should not be used until it is repaired.

The product is intended for use at home and commercial use and may not be used for other than intended use.

The manufacturer is not liable for damages resulting from not adhering to the rules contained in the user manual, therefore, we recommend to follow the aforementioned safety rules for operation and maintenance of the device. In this way you will ensure yourself safety and avoid causing damage to the device.

The manufacturer and the supplier are not liable for losses or damages arising out of the product, including financial or intangible losses, loss of profits, income, data, pleasure from use of the product or other products related with it - indirect, incidental or consequential loss or damage. The above provisions apply whether the loss or damage concerns:

- 1. Deterioration of quality or the lack of operation of the products or products related with it due to damage as well as the lack of access to the product when it is undergoing repair, which results in stoppage the loss of user's time or a break in business activity;
- 2. Improper results of operation of the product or products related with it;
- 3. It applies to losses and damages according to any legal category, including negligence and other losses, termination of a contract, expressed or implied guarantee and strict liability (even if the manufacturer or the supplier was notified about the possibility of occurrence of such damages).

#### Safety measures:

Particular attention at designing was directed to quality standards of the device where ensuring safety of operation is the most important factor.

The device must be secured against contact with caustic, staining and viscous fluids.

The device was designed in such a way that it restarts operation when power supply is restored after a break.

Attention! We recommend using protections to further protect the device from possible overvoltages in installations. Surge protectors are effective protection against accidental pass to the device voltages higher than the rated. Damages caused by pass the voltages higher than specified in manual, are not under warranty.

Turn off the device before transporting it.

Prior to connecting the device to a power source check whether the supplied voltage is consistent with rated voltage specified in the user manual.

#### Proper product disposal:

A marking of a crossed out waste bin indicates that the product may not be disposed together with other household waste in the entire EU. To avoid possible damage to the natural environment of health due to uncontrolled waste disposal, therefore, it should be handed over for recycling, propagating in this way sustainable use of natural resources.

To return a worn-out product, use a collection and disposal system of this type of equipment or contact a seller from whom it was purchased. He will then be recycled in an environmentally-friendly way.

Advanced alarm control unit providing alarm functions and optional implementation of home automation and access

Thanks to their full compliance with the EN50131 Grade 3 requirements, the INTEGRA Plus series control panels provide a perfect solution for implementing advanced security systems in facilities subject to considerable burglary risk, e.g. banks, jewelery shops or public utility buildings. A major advantage of the INTEGRA control units are their communication features combined with additional modules - GSM and TCP/IP. System operation is possible with LCD keypads, partition keypads, keyfobs and proximity cards or remotely with PC or mobile phone. Flash firmware upgrade with a PC.





DELTA-OPTI Monika Matysiak; https://www.delta.poznan.pl POL; 60-713 Poznań; Graniczna 10 e-mail: delta-opti@delta.poznan.pl; tel: +(48) 61 864 69 60



# User Manual

# Code: INTEGRA-128-PLUS/IT ALARM CONTROL PANEL INTEGRA-128-PLUS/IT SATEL

Mainboard inputs:	16 pcs
Mainboard outputs:	16 pcs
Maximal number of supported inputs:	128 pcs
Maximal number of supported outputs:	128 pcs
Current-carrying capacity, low-current programmable outputs:	50 mA
Current-carrying capacity, high-current programmable outputs (+/-10%):	3 A - 4 pcs
Maximal load:	3.5 A
Users + admins:	240 + 8
Partitions:	8
Zones:	32
Expansion modules:	max. 64
Events memory:	22527
Timers:	64
Supported keypads:	max. 8 pcs
Supporting the wireless ABAX system via bus:	<b>✓</b>
Keyboard included:	-
Enclosure included:	1
Protection class (Grade):	3
Main features:	<ul> <li>Access control and home automation functions</li> <li>Built-in advanced power adapter with extended diagnostics</li> <li>Control panel programming and firmware upgrade via mini USB socket</li> </ul>
Power supply:	20 V AC / 337 mA
Operation temp:	-10 °C 55 °C
Permissible relative humidity:	93 %
Dimensions:	264 x 134 mm
Weight:	0.29 kg
Supported languages:	Italian
Manufacturer / Brand:	SATEL
Guarantee:	2 years

 $Control\ panel\ main board:$ 






## User Manual

Code: INTEGRA-128-PLUS/IT
ALARM CONTROL PANEL INTEGRA-128-PLUS/IT SATEL



In the kit:



**PACKAGE** 

Dimensions (L x W x H): 0x0x0 mm Gross Weight: 0 kg