



# User Manual

Code: BML-XK20

LASER FIBER TESTER **BML-XK20** 650 nm > 20 mW > 10 km

## Warning!

Please read the user manual included in this work as it contains important information related with safety of installation and use of the device.

Only persons who read the user manual may use the device.

The user manual must be kept because it may be required in the future. The device is to be used exclusively for purposes specified in this user manual.

The device must be unpacked prior to starting-up. After removing the packaging make sure the device is in working order.

If the product has defects, it should not be used until it is repaired.

The product is intended for use at home and commercial use and may not be used for other than intended use.

The manufacturer is not liable for damages resulting from not adhering to the rules contained in the user manual, therefore, we recommend to follow the aforementioned safety rules for operation and maintenance of the device. In this way you will ensure yourself safety and avoid causing damage to the device.

The manufacturer and the supplier are not liable for losses or damages arising out of the product, including financial or intangible losses, loss of profits, income, data, pleasure from use of the product or other products related with it - indirect, incidental or consequential loss or damage. The above provisions apply whether the loss or damage concerns:

1. Deterioration of quality or the lack of operation of the products or products related with it due to damage as well as the lack of access to the product when it is undergoing repair, which results in stoppage the loss of user's time or a break in business activity;
2. Improper results of operation of the product or products related with it;
3. It applies to losses and damages according to any legal category, including negligence and other losses, termination of a contract, expressed or implied guarantee and strict liability (even if the manufacturer or the supplier was notified about the possibility of occurrence of such damages).

### Safety measures:

Particular attention at designing was directed to quality standards of the device where ensuring safety of operation is the most important factor.

The device must be secured against contact with caustic, staining and viscous fluids.

The device was designed in such a way that it restarts operation when power supply is restored after a break.

**Attention! We recommend using protections to further protect the device from possible overvoltages in installations. Surge protectors are effective protection against accidental pass to the device voltages higher than the rated. Damages caused by pass the voltages higher than specified in manual, are not under warranty.**

Turn off the device before transporting it.

Prior to connecting the device to a power source check whether the supplied voltage is consistent with rated voltage specified in the user manual.

### Proper product disposal:

A marking of a crossed out waste bin indicates that the product may not be disposed together with other household waste in the entire EU. To avoid possible damage to the natural environment of health due to uncontrolled waste disposal, therefore, it should be handed over for recycling, propagating in this way sustainable use of natural resources.

To return a worn-out product, use a collection and disposal system of this type of equipment or contact a seller from whom it was purchased. He will then be recycled in an environmentally-friendly way.

The BML-XK20 Laser Fiber Tester enables optical localization of the fiber damages (Visual Fault Locator - VFL) and allows to quickly and accurately locate the break point or fracture of the fiber. The device generates visible light of wavelength 650nm. A laser with a power of 20 mW allows to check the fiber cable with a maximum length of >10 km. In addition, the device has the ability to operate in both continuous and pulsed modes.

Selection the technical parameters of the device in combination with small dimensions makes the BML-XK20 visual locator the perfect choice for any fiber optic installer. The universal connector allows to connect all optical connectors of 2.5 mm standard, eg SC/FC/ST.

**WARNING!** Avoid directing the laser beam towards the skin and eyes when using this product.



Optical wavelength:	650 nm $\pm$ 20 nm
Optical output power:	> 20 mW
Operation range:	> 10 km
Connector type:	Universal
Application:	Visual localization of the fiber damage
Operation mode:	<ul style="list-style-type: none"> <li>CW - continuous</li> <li>GLINT - pulsating light (pulsation frequency: 2 Hz)</li> </ul>
Main features:	<ul style="list-style-type: none"> <li>The universal connector allows to connect all optical connectors of 2.5 mm standard, eg SC/FC/ST</li> <li>Universal connector allows to test any fiber optic installation</li> <li>The device works with both single-mode and multi-mode fibers</li> <li>Backup time : <math>\leq</math> 60 h</li> <li>Mounted shield protects unused socket against dust</li> <li>Small dimensions</li> </ul>
Material:	Aluminum
Power supply:	2 x 1.5 V - Battery type LR6 (AA) (included)
Weight:	0.075 kg
Dimensions:	$\varnothing$ 30 x 180 mm
Guarantee:	2 years






# User Manual

Code: BML-XK20

LASER FIBER TESTER **BML-XK20** 650 nm > 20 mW > 10 km



In the kit:



## PACKAGE

Dimensions (L x W x H): 0x0x0 mm	Gross Weight: 0 kg
----------------------------------	--------------------