



User Manual

Code: ALINK-MR920

ACCESS POINT 4G LTE +ROUTER **ALINK-MR920** 2.4 GHz 300 Mbps

Warning!

Please read the user manual included in this work as it contains important information related with safety of installation and use of the device.

Only persons who read the user manual may use the device.

The user manual must be kept because it may be required in the future. The device is to be used exclusively for purposes specified in this user manual.

The device must be unpacked prior to starting-up. After removing the packaging make sure the device is in working order.

If the product has defects, it should not be used until it is repaired.

The product is intended for use at home and commercial use and may not be used for other than intended use.

The manufacturer is not liable for damages resulting from not adhering to the rules contained in the user manual, therefore, we recommend to follow the aforementioned safety rules for operation and maintenance of the device. In this way you will ensure yourself safety and avoid causing damage to the device.

The manufacturer and the supplier are not liable for losses or damages arising out of the product, including financial or intangible losses, loss of profits, income, data, pleasure from use of the product or other products related with it - indirect, incidental or consequential loss or damage. The above provisions apply whether the loss or damage concerns:

1. Deterioration of quality or the lack of operation of the products or products related with it due to damage as well as the lack of access to the product when it is undergoing repair, which results in stoppage the loss of user's time or a break in business activity;
2. Improper results of operation of the product or products related with it;
3. It applies to losses and damages according to any legal category, including negligence and other losses, termination of a contract, expressed or implied guarantee and strict liability (even if the manufacturer or the supplier was notified about the possibility of occurrence of such damages).

Safety measures:

Particular attention at designing was directed to quality standards of the device where ensuring safety of operation is the most important factor.

The device must be secured against contact with caustic, staining and viscous fluids.

The device was designed in such a way that it restarts operation when power supply is restored after a break.

Attention! We recommend using protections to further protect the device from possible overvoltages in installations. Surge protectors are effective protection against accidental pass to the device voltages higher than the rated. Damages caused by pass the voltages higher than specified in manual, are not under warranty.

Turn off the device before transporting it.

Prior to connecting the device to a power source check whether the supplied voltage is consistent with rated voltage specified in the user manual.

Proper product disposal:

A marking of a crossed out waste bin indicates that the product may not be disposed together with other household waste in the entire EU. To avoid possible damage to the natural environment of health due to uncontrolled waste disposal, therefore, it should be handed over for recycling, propagating in this way sustainable use of natural resources.

To return a worn-out product, use a collection and disposal system of this type of equipment or contact a seller from whom it was purchased. He will then be recycled in an environmentally-friendly way.

The ALINK-MR920 Wireless Router, operating in accordance with the 802.11 b/g/n standard, allows to share a network connection between several users in areas that are covered by 3G/4G signal.

Main applications include Internet accesses in small and medium size businesses, SOHO, and homes.

The device does not require any additional configuration, it is ready to use immediately after placing the SIM card inside and connecting the power supply.



Frequency range:	2.4 GHz
Antenna type:	2 x Omnidirectional antenna Wi-Fi - 8 dBi, 4G LTE
Standards:	IEEE 802.11 b/g/n, 4G LTE, 3G
Baud rates:	11n : 300 Mbps 11g : 54 Mbps 11b : 11 Mbps LTE : 150 / 50 Mbps
LAN ports:	<ul style="list-style-type: none"> • 1 x 10/100 Mbps - LAN/WAN • 2 x 10/100 Mbps - LAN
Receiver sensitivity:	<ul style="list-style-type: none"> • 11g 54M : -74 dBm • 11n HT20 MCS7 : -71 dBm • 11n HT40 MCS7 : -67 dBm
Transmitter power:	< 27 dBm @ 2.4 GHz
LED indicators:	Power, WAN, WLAN, LAN, GSM
Network type:	<ul style="list-style-type: none"> • 4G : FDD-LTE B1/B3/B7/B8/B20/B28 - 2100 / 1800 / 2600 / 900 / 800 / 700 MHz • 4G : TDD-LTE B38/B40/B41 - 2600 / 2300 / 2500 MHz • 3G : DC-HSPA+/HSPA/UMTS B1/B8 - 2100 / 900 MHz
LTE:	✓
QSS:	—
WDS:	—

DHCP server:	✓
Protections:	<ul style="list-style-type: none"> • WPA-PSK/WPA2-PSK • SSID hiding • MAC addresses filtering
Management interface:	Web browser
Main features:	<ul style="list-style-type: none"> • SIM socket • ON/OFF button • WPS/RESET button • DHCP client/server support • DHCP client list • Static routing • Default address : 192.168.1.1 • WAN Connection Backup - thanks to the fully functional WAN / LAN port, you can use various types of backup connections, including cable, fiber and DSL modems
Power supply:	<ul style="list-style-type: none"> • 12 V DC / 1 A (power adapter included) • 5 V / 2 A via micro USB port
Operation temp:	0 °C ... 40 °C
Permissible relative humidity:	10 % ... 90 % (non-condensing)
Weight:	0.32 kg
Dimensions:	200 x 145 x 49 mm
Manufacturer / Brand:	ALINK
Guarantee:	2 years

Front view:





Rear panel:






Top view (control keys visible):



Bottom view (after remove the cover):



Connectors:






User Manual

Code: ALINK-MR920

ACCESS POINT 4G LTE +ROUTER **ALINK-MR920** 2.4 GHz 300 Mbps



Example captures of device interface:




In the kit:



User Manual

Code: ALINK-MR920

ACCESS POINT 4G LTE +ROUTER **ALINK-MR920** 2.4 GHz 300 Mbps



PACKAGE

Dimensions (L x W x H): 0x0x0 mm	Gross Weight: 0 kg
----------------------------------	--------------------